

Relay Control



Supported on Hello Hub V1, V2 and Microservers.

You can control the physical world with a Hello Hub and **ring-u** phone system! Need to open a door, turn on lights, or a siren? Maybe ring a bell or open a gate? In July 2020, the geeks at **ring-u** added support for the popular Sainsmart and compatible 4 and 8 channel/relay modules. Similar **FT245RL** chip controlled units via USB should also work. These are usually also available on [Amazon.com](https://www.amazon.com), the links below have better specs and wiring information.

Note: If the board relays say 12V on them, you need 12 Volts DC to operate the board.

- [4 relay 5vdc power](#)
- [8 relay 12vdc power](#)

Caveats

- **ring-u** will need to add the apropos driver to your Hello Hub for it to work properly. Contact support at ring-u.com prior to installation.
- The customer will require some expertise to interface these to your desired application. We can offer advice, but you may need to hire an expert with some skills and ancillary parts ring-u does not supply.
- The customer should use the ancillary power inputs, so the relays do not cycle on Hello Hub power up or reset, which it will do if only using the USB power via the on-board jumper.
- If used for door striker locks, or gate controls, you should also have deadbolts or other mechanisms in place to be used as apropos when you don't want the phone system to control the relays.
- **ring-u** is not liable for the usage of these features, many variables beyond our control.

Example usage

- Relay 1 is connected to the front door striker plate that “buzzes people in”. Dialing 441 will operate/power that door striker plate for 5 seconds.
- Relay 2 is connected to the back door striker plate that “buzzes people in”. Dialing 442 will operate/power that door striker plate for 5 seconds.

- Relay 3 controls a light, dialing 452 will turn it on, dialing 462 will turn it off.
- Relay 4 controls an alarm system panic switch. Dialing 444 sets off the alarm.

Control Codes

These codes will work from any local extension on the system. This may include remote extensions. These codes will not work for unauthenticated callers or inbound calls (guests). The “off” codes (440,450,460) are a bit redundant. The usage of what code does what, is up to the installation.

relay	momentary (5 second)	on	off
all-off	440 all-off	450 all-off	460 all-off
1	441	451	461
2	442	452	462
3	443	453	463
4	444	454	464
5	445	455	465
6	446	456	466
7	447	457	467
8	448	458	468
all	449	459	469

From:

<https://wiki.ring-u.com/wiki/> - support wiki

Permanent link:

<https://wiki.ring-u.com/wiki/doku.php?id=relay&rev=1643895490>

Last update: **2022/02/03 13:38**

