

Ubiquiti UDM Pro

Advanced Settings for Dream Machine Pro (UDM Pro).

Search for SIP or Timeout. Adjust as below.

Under **Firewall Connection Tracking** (bottom of below image), make sure that **SIP** is not enabled. If there is a gray box showing SIP, that means it is enabled and you must click the **X** to dismiss/disable it.

Timeout should be set to a number greater than 600 seconds. 620 is recommended as our phones use 600.

Number of Seconds

620

Auto Firewall State Timeouts

Global NAT Settings [\(i\)](#)

Auto

Firewall Connection Tracking [\(i\)](#)

FTP H.323 GRE PPTP TFTP

[Edit \(5\)](#)

From:
<https://wiki.ring-u.com/wiki/> - support wiki



Permanent link:
<https://wiki.ring-u.com/wiki/doku.php?id=ubiquiti-advanced>

Last update: **2026/02/19 20:45**