

# Ubiquiti UDM Pro

Advanced Settings for Dream Machine Pro aka UDP Pro

Search for SIP or Timeout. Adjust as below. Make sure there is **NOT SIP** enabled under NAT “helpers”

Also set the timeout to a number greater than 600 seconds. 620 is recommended as the phones use 600.

Number of Seconds

620

Auto Firewall State Timeouts

Global NAT Settings ⓘ

Auto

Firewall Connection Tracking ⓘ

FTP × H.323 × GRE × PPTP × TFTP ×

[Edit \(5\)](#)

From:  
<https://wiki.ring-u.com/wiki/> - support wiki

Permanent link:  
<https://wiki.ring-u.com/wiki/doku.php?id=ubiquiti-advanced&rev=1771532771>

Last update: **2026/02/19 20:26**

