

Ubiquiti UDM Pro



Advanced Settings for Dream Machine Pro (UDM Pro).

Search for SIP or Timeout. Adjust as below.


Under **Firewall Connection Tracking** (bottom of below image), make sure that **SIP** is not enabled. If there is a gray box showing SIP, that means it is enabled and you must click the **X** to dismiss/disable it.

Timeout should be set to a number greater than 600 seconds. 620 is recommended as our phones use 600.


Number of Seconds






620  

Auto Firewall State Timeouts

Global NAT Settings 

Auto

Firewall Connection Tracking 

FTP  H.323  GRE  PPTP  TFTP 

[Edit \(5\)](#)

From:

<https://wiki.ring-u.com/wiki/> - support wiki

Permanent link:

<https://wiki.ring-u.com/wiki/doku.php?id=ubiquiti-advanced&rev=1771533943>

Last update: 2026/02/19 20:45

