## **Restore to Factory Default Settings**

(GRP2614, 2615, 2616)

Warning: Restoring the Factory Default Settings will delete all configuration information on the phone. Any user-created settings will be lost. To reconfigure, go to Configuration > Extensions > Extension Number and re-save.

## To restore factory settings using LCD menu:

Please follow the instructions below to reset the phone:

- 1. 1. From the Home Screen, press the Round button between the 4 arrow buttons.
- 2. 2. Navigate to **System > Operations Factory Reset** and press **Enter**.
- 3. 3. A warning window will pop out to make sure a reset is requested and confirmed.
- 4. 4. Press the **Yes** soft key to confirm and the phone will reboot, or **No** soft key to cancel the reset.



From:

https://wiki.ring-u.com/wiki/ - support wiki

Permanent link:

https://wiki.ring-u.com/wiki/doku.php?id=factory-reset-2614-16&rev=1676484098

Last update: 2023/02/15 18:01

