

Restore to Factory Default Settings - GRP2614, GRP2615, GRP2616

Warning: Restoring the Factory Default Settings will delete all configuration information on the phone. Any user-created settings will be lost. To reconfigure, go to Configuration > Extensions > Extension Number and re-save.

To restore factory settings using LCD menu:

Please follow the instructions below to reset the phone:

1. From the Home Screen, press the Round button between the 4 arrow buttons.
2. Navigate to **System > Operations - Factory Reset** and press **Enter**.
3. A warning window will pop out to make sure a reset is requested and confirmed.
4. Press the **Yes** soft key to confirm and the phone will reboot, or **No** soft key to cancel the reset.



From:

<https://wiki.ring-u.com/wiki/> - support wiki

Permanent link:

<https://wiki.ring-u.com/wiki/doku.php?id=factory-reset-2614-16&rev=1676565763>

Last update: **2025/11/02 18:50**

