2025/12/01 08:10 1/1 Grandstream WP820



Grandstream WP820

Connecting the WP820 to WiFi

With the WP820 powered on:

- 1. Press Menu
- 2. Navigate to the Settings menu (gear icon) > Network Settings > Wi-Fi Settings
- 3. Set WiFi to On.
- 4. Go down to Wi-Fi Settings and select the correct network from the displayed list.
- 5. Enter the password. Special characters are available via the * key.

×

Note - Sometimes the WP820 can take a while to apply a configuration file. Often, it can take 3-4 hours. Other times, it can happen in minutes. The good news is that once connected and configured, the WP820 is an incredibly stable workhorse.

From:

https://wiki.ring-u.com/wiki/ - support wiki

Permanent link:

https://wiki.ring-u.com/wiki/doku.php?id=grandstream-wp820

Last update: 2025/11/02 18:49

