



Grandstream WP820

Connecting the WP820 to WiFi

With the WP820 powered on:

1. Press **Menu**
2. Navigate to the **Settings** menu (gear icon) > **Network Settings** > **Wi-Fi Settings**
3. Set WiFi to **On**.
4. Go down to **Wi-Fi Settings** and select the correct network from the displayed list.
5. Enter the password. Special characters are available via the * key.



Note - Sometimes the WP820 can take a while to apply a configuration file. Often, it can take 3-4 hours. Other times, it can happen in minutes. The good news is that once connected and configured, the WP820 is an incredibly stable workhorse.

From:

<https://wiki.ring-u.com/wiki/> - support wiki

Permanent link:

<https://wiki.ring-u.com/wiki/doku.php?id=grandstream-wp820&rev=1762109398>

Last update: 2025/11/02 18:49

