

# Power Supply Stats for Hello Hub v1 and v2

## How to use



1

Confirm whether our adapter are suitable for your device

2

Check the polarityoc



3

Plug the adapter into outlet

DC connector size

Diameter: 5.5mmx2.5mm



<https://a.co/d/2HywvJ6>

From:

<https://wiki.ring-u.com/wiki/> - support wiki

Permanent link:

<https://wiki.ring-u.com/wiki/doku.php?id=hps-stats&rev=1761321031>

Last update: 2025/11/02 18:50

