

Power Supply Stats for Hello Hub v1 and v2

How to use



1 Confirm whether our adapter are suitable for your device



2 Check the polarityoc



3 Plug the adapter into outlet

DC connector size

Diameter: 5.5mmx2.5mm



<https://a.co/d/2HywvJ6>

From: <https://wiki.ring-u.com/wiki/> - support wiki

Permanent link: <https://wiki.ring-u.com/wiki/doku.php?id=hps-stats&rev=1762109398>

Last update: 2025/11/02 18:49

