

Getting to Know the Keypad - GRP2614, GRP2615, GRP2616

GRP2614



GRP2615



GRP2616



GRP2614 / GRP2615 / GRP2616 Keypad Buttons

Icon	Button	Function
	Contacts	Press to view and edit contact information.
	Hold	Press to put call on hold or resume the call.
	Mute	Press to mute or unmute the call.
	Headset	Press to switch to Headset mode.
	Message	Press to access Voicemail messages.
	Transfer	Press to transfer call.
	Conference	Press to conference call.
	Speaker	Press to use speaker phone.
	Send/Redial	Press to send call or redial.
	Volume	- (left) decreases volume / + (right) increases volume.
	Navigation keys (4)	Navigate menu options. When on idle screen, press up for 3 seconds to display IP info.
	Menu	Press to access menu.

From:

<https://wiki.ring-u.com/wiki/> - support wiki

Permanent link:

<https://wiki.ring-u.com/wiki/doku.php?id=keypad-2614-16&rev=1676559125>

Last update: 2025/11/02 18:50

