

How to Use Your GRP26xx Series Phone

Getting to Know the Keypad - GRP2614, GRP2615, GRP2616

GRP2614



GRP2615



GRP2616



GRP2614 / GRP2615 / GRP2616 Keypad Buttons

Icon	Button	Function
	Contacts	Press to view and edit contacts. information.
	Hold	Press to put call on hold or resume the call. Can only be resumed from the same phone. Video: Hold vs. Park
	Mute	Press to mute or unmute your handset microphone while on a call. Pressing this button when not on a call will put the phone in Do Not Disturb mode and will break inbound Ring Groups (not recommended).
	Headset	Press to switch to Headset mode.
	Message	Press to access Voicemail messages for the extension associated with that extension only.
	Transfer	Press to initiate call transfer. You will have the option to choose either an Attended Transfer or a Blind Transfer.
	Conference	Press to initiate a conference call.
	Speaker	Press to use speaker phone.
	Send/Redial	Press to send call or redial.
	Volume	- (left) decreases volume / + (right) increases volume.
	Navigation keys (4)	Navigate menu options. When on idle screen, press up for 3 seconds to display IP info.
	Menu	Press to access menu.

Other functions: Call any internal extension (including softphones), by either pressing the button on the lower BLF screen, or dialing the extension number.

Intercom (or Auto-Answer Intercom) allows a caller to dial an extension and speak through the receiving ends speaker phone automatically. This function must be enabled for each extension in the Advanced Tab of each extension's page in your Portal ([Extensions Functions/Settings](#)).

Paging via overhead speakers requires special group setup and may require additional special equipment. Please submit a ticket through your customer portal or call us at 423-567-4888 to discuss.

Notes *The Lines keys on the left side of your phone's screen should not be pressed. They do not do what*

other phone companies' buttons do. No touchy!

From:

<https://wiki.ring-u.com/wiki/> - **support wiki**

Permanent link:

<https://wiki.ring-u.com/wiki/doku.php?id=keypad-2614-16&rev=1762453897>

Last update: **2025/11/06 18:31**

