Ubiquiti ER X Configs

Edgerouter X with ring-u Hello Hub & Port Forwarding for External Remote Phones

Some screen shots of a working Edgerouter X configuration including Port Forwarding, and Static DHCP Leases.






EdgeMAX
EdgeRouter X v1.10.11
CPU: 2%
RAM: 29%
Uptime: 2 weeks, 6 hours, 34 minutes
UNMS
CLI
Toolbox
Welcome ubnt
to ubnt
Dashboard
Traffic Analysis
Routing
Firewall/NAT
Services
VPN
QoS
Users
Config Tree
Wizards
Port Forwarding
Firewall Policies
NAT
Firewall/NAT Groups
Show advanced options
WAN interface
eth0
Hairpin NAT
Enable hairpin NAT (also known as "NAT loopback" or "NAT reflection")
LAN interface
eth1
Remove LAN
Add LAN
Port forwarding rules
Show rules stats
Original port
Protocol
Forward-to address
Forward-to port
Description
5060-200(
Both
192.168.77.22
5060-200(
VoIP
Remove Rule
Add Rule
Delete
Cancel
Apply


EdgeMAX
EdgeRouter X v1.10.11
CPU: 5%
RAM: 29%
Uptime: 2 weeks, 6 hours, 35 minutes
UNMS
CLI
Toolbox
Welcome ubnt
to ubnt
Dashboard
Traffic Analysis
Routing
Firewall/NAT
Services
VPN
QoS
Users
Config Tree
Port Forwarding
Firewall Policies
NAT
Firewall/NAT Groups
Add Source NAT Rule
Save Rule Order
Search
Order
Description
Source
Destination
Translation
Count
1
masquerade for WAN
masquerade to eth0
890814
Actions
Showing 1 to 1 of 1 entries
Previous
Add Destination NAT Rule
Save Rule Order
Search
Order
Description
Source
Destination
Translation
Count
No rules available.



From:
https://wiki.ring-u.com/wiki/ - **support wiki**

Permanent link:
https://wiki.ring-u.com/wiki/doku.php?id=ubiquiti-erx-configs

Last update: **2025/11/02 18:49**